

D500 Settings

06.08.16

## PLAYBACK MENU

Delete

Playback folder > ALL

Hide image

Playback display options > Basic photo info > Highlights  
> Shooting data  
> Overview

Copy images(s) --

Image review > OFF

After delete > Show next

After burst, shot > First image in burst

Auto image rotation > ON

Rotate tall > OFF

Slide show --

Select to send to smart device

## SHOOTING MENU

Photo shooting menu bank > A

Extended photo menu banks > OFF

Storage folder > ND500

File naming > BMP

Primary slot selection > XQD

Role played by card in Slot > Overflow

(With WT-R10 is PLUGGED into D5)

Flash control > CMD ⚡ > Wireless flash options > Radio AWL

Remote flash control > A:B ⚡

Quick wireless control options -- > Output (A:B) > 1:1  
> Compensation -0. 0  
> Group C --

Choose image area > DX

Image quality > Raw

Image size > JPEG/TIFF > Image size L  
> NEF (RAW) > RAW L >

NEF (RAW) recording > NEF (RAW) compression ON > ON Lossless compressed  
> NEF (RAW) bit depth 14-bit > 14-bit

ISO sensitivity settings > 100  
> Auto ISO sensitivity control > OFF

White balance > Auto2

Set Picture Control > Standard > Sharpening 5 (my default)  
> Vivid > Sharpening 5  
> Landscape > Sharpening 5  
> Flat > Sharpening 5

Manage Picture Control --  
Color Space > Adobe  
Active D-Lighting > OFF  
Long exposure NR > OFF  
High ISO NR > OFF  
Vignette control > N  
Auto distortion control > ON  
Flicker reduction --  
Auto bracketing set > AE ⚡  
Multiple exposure > OFF -- When > ON  
    > Series On  
    > Number of shots 10  
    > AVG (changed as needed with new features)  
HDR (high dynamic range) > OFF  
Interval timer shooting > OFF

### **MOVIE SHOOTING MENU**

Reset movie shooting menu--  
File naming > BMP  
Destination > SD card slot  
Choose Image area > DX  
Frame size/frame rate > 2160p 25  
Movie quality > HIGH  
Movie ISO sensitivity settings > ISO sensitivity (mode M) > 100  
    > Auto ISO control (mode M) > ON  
    > Maximum sensitivity > 16000  
White balance > Auto2  
Set Picture Control > Same as photo settings  
Manage Picture Control --  
Active D-Lighting - OFF  
High ISO NR > OFF  
Flicker reduction > Auto  
Microphone sensitivity > Manual sensitivity > 10  
Frequency response > Voice  
Wind noise reduction > OFF  
Time-lapse movie > OFF  
Electronic VR

### **CUSTOM SETTING MENU**

Custom settings bank > A  
a Autofocus  
    a1\* AF-C priority selection > Focus & release  
    a2 AF-S priority selection > Focus  
    a3\* Focus tracking with lock-on > Blocked shot AF response > 2  
        > Subject motion > center  
    a4\* 3D-tracking face-detection > ON

- a5 3D-tracking watch area > NORM
- a6 Number of focus points > AF55
- a7\*Store by orientation > Focus point
- a8 AF activation > ON
- a9\* Limit AF-area mode selection > Dynamic-area AF (153 point)
  - > Group-area AF
  - > Auto-area AF
- a10\* Autofocus mode restrictions > AF-C
- a11\*Focus point wrap-around > ON
- a12\* Focus point options > Manual focus mode > ON
  - > Dynamic-area AF assist > ON
  - > Group-area AF display > dots
  - > Focus point illumination > Auto

#### b Metering/exposure

- b1 ISO sensitivity step value > 1/3
- b2 EV steps for exposure cntrl > 1/3
- b3 Exp./flash comp. step value > 1/3
- b4 Easy exposure compensation > OFF
- b5 Matrix metering > Face detection on
- b6 Center-weighted area > (●)8
- b7 Fine-tune optimal exposure --

#### c Timers/AE lock

- c1 Shutter-release button AE-L > OFF
- c2\* Standby timer > 10s
- c3 Self-timer --
- c4\* Monitor off delay > --


#### d Shooting/display

- d1 CL mode shooting speed > 5
- d2 Max. continuous release > 200
- d3 ISO display > Show frame count
- d4 Sync. release mode option > Sync
- d5 Exposure delay mode > OFF
- d6 Electronic front-curtain shutter > OFF
- d7 File number sequence > ON
- d8\* Viewfinder grid display > ON
- d9 LCD illumination > OFF

#### e Bracketing/flash

- e1\* Flash sync speed > 1/250\*
- e2\* Flash shutter speed > 1/15
- e3\* Exposure comp. for flash > Background only
- e4 Auto ⚡ ISO sensitivity control > Subject and background
- e5 Modeling flash > ON
- e6 Auto bracketing (Mode M) – Flash/speed
- e7\*Bracketing order > Under>MTR>over

#### f Controls

- f1\* Custom control assignment > Pv > ⚡ Disable/enable flash
    - > Fn1 > AF Area mode > Auto-area AF
  - f2 Multi selector center button > Shooting mode > RESET
    - > Playback mode > Zoom on/off > Low magnification (50%)
    - > Live view > RESET
  - f3 Shutter spd & aperture lock - -
  - f4\* Customize command dials > Reverse rotation > Exposure compensation
    - > Change main/sub > Exposure setting > OFF
      - > Autofocusing setting > OFF
    - > Aperture setting > ON
    - > Menus and playback > ON
    - > Sub-dial frame advance > 10
  - f5 Multi selector > OFF
  - f6 Release button to use dial > OFF
  - f7 Reverse indicators > - 0 +
  - f8 Live view button options > ON
  - f9  switch
  - f10 Assign MB-D17 buttons
- g Movie
- g1\* Custom control assignment > Pv > Power aperture (open)
    - > Shutter Release > Record movies

## SETUP MENU

- Format memory card - -
- Language > Dansk
- Time zone and date > (always set to current location)
- Monitor brightness > 0
- Monitor color balance - -
- Virtual horizon - -
- Information display > Auto
- AF fine-tune - -
- Non-CPU lens data > No.1
- Clean image sensor > Clean at startup/shutdown > Clean at startup & shutdown
- Lock mirror up for cleaning - -
- Image Dust Off ref photo - -
- Image comment > OFF
- Copyright information > ON
- IPTC
- Beep > Volume > OFF
  - > Pitch > L
- Touch controls > ON
- HDMI > Output Resolution > AUTO
  - > Advanced > Output range > Limit
    - > Output display size > 100%
    - > Live view on-screen display > OFF

> Dual monitor > ON

Location data > Download from smart device > ON

> Position

> External GPS device options > ON

> ON

Wireless remote (WR) options

Assign remote (WR) Fn button > Live view

Airplane mode > ON

Connect to smart device –

Send to smart device (auto) > OFF

Wi-Fi > ON

Bluetooth OFF

Network

Conformity marking –

MB-D17 battery type

Battery order > MB-D17

Battery info --

Slot empty release lock > OK

Save/load settings - -

Reset all settings --

Firmware version - -

## MY MENU

Time zone and date

Flash control

Time-lapse photography

Movie quality

Multiple exposure

Microphone sensitivity

Lock mirror up for cleaning

blank = default

\* = modified