

D850 Settings

10.03.17

## **PLAYBACK MENU**

Delete

Playback folder – ALL

Hide image

Playback display options > Additional photo info > None

Highlights

Shooting data

Overview

Copy images(s)

Image review - OFF

After delete > Continue as before

After burst, show > First image in burst

Auto image rotation > OFF

Rotate tall – ON

Slide show - -

Select to send to smart device

## **SHOOTING MENU**

Shooting menu bank – A

Extended photo menu banks – OFF

Storage folder – ND850

File naming – BMP

Primary slot selection > XQD

Secondary slot function > Overflow

Flash Control (grayed out unless WR-R10 connected) > Flash control mode

> Flash compensation (TTL)

> Wireless flash options > Radio AWL

> Remote flash control > A:B

> Quick wireless control options >

> Radio remote flash info

Image area > Choose image area > FX

> Auto DX crop > ON

> Viewfinder mask display > ON

Image quality > Raw

Image size > JPEG/TIFF > L

> NEF (RAW) > RAW L

NEF (RAW) recording > NEF (RAW) compression > ON Lossless compressed

> NEF (RAW) bit depth > 14-bit

ISO sensitivity settings > 64

> Auto ISO sensitivity control – OFF

White balance > Auto > A Natural light auto

Set Picture Control > A Auto

> Standard > Sharpening 5 > Clarity +1

>Flat > Sharpening 5 > Clarity +1

Manage Picture Control

Color Space > Adobe RGB

Active D-Lighting – OFF

Long exposure NR – OFF

High ISO NR – OFF

Vignette control – N

Auto distortion control – ON

Flicker reduction - -

Auto bracketing set > AE

Multiple exposure – OFF

HDR (high dynamic range) (grayed out)

Interval timer shooting – OFF

Focus shift shooting – OFF

Silent live view photography > SL1

### **MOVIE SHOOTING MENU**

Reset movie shooting menu - -

File naming > BMP

Destination > SD

Image area > - -

Frame size/frame rate > 3840; 30p

Movie quality > HIGH (grayed out)

Movie file type > MOV

ISO sensitivity settings > Maximum sensitivity > 6400

> Auto ISO control (mode M) > OFF

> ISO sensitivity (mode M) > 64

White balance > Same as photo settings

Set Picture Control > FL\*

Manage Picture Control > - -

Active D-Lighting > OFF (grayed out)

HIGH ISO NR > OFF

Flicker reduction > Auto

Microphone sensitivity > Manual sensitivity > 10

Attenuator > OFF

Frequency response > WIDE

Wind noise reduction > ON

Electronic VR > OFF (grayed out)

Time-lapse movie – OFF

### **CUSTOM SETTING MENU**

Custom settings bank – A

a Autofocus

a1\* AF-C priority selection > Release + focus

a2 AF-S priority selection > focus

a3\* Focus tracking with lock-on > Blocked shot AF response > 2

> Subject motion > center

- a4\* 3D-tracking face-detection > ON
- a5 3D-tracking watch area > NORM
- a6 Number of focus points > AF55
- a7\* Store by orientation > Focus point
- a8\* AF activation > OFF
- a9\* Limit AF-area mode selection > Single-point AF
  - > Group-area AF
  - > Auto-area AF
- a10 Autofocus mode restrictions > OFF
- a11\* Focus point wrap-around > ON
- a12 Focus point options

b Metering/exposure

- b1 ISO sensitivity step value > 1/3
- b2 EV steps for exposure cntrl > 1/3
- b3 Exp./flash comp. step value > 1/3
- b4 Easy exposure compensation – OFF
- b5 Matrix metering > Face detection on
- b6 Center-weighted area – (●)8
- b7 Fine-tune optimal exposure - -

c Timers/AE lock

- c1 Shutter-release button AE-L > OFF
- c2 Standby timer > 6s
- c3 Self-timer - -
- c4 Monitor off delay - -

d Shooting/display

- d1 CL mode shooting speed > 5 fps
- d2 Max. continuous release > 200
- d3\* ISO display > OFF
- d4 Sync. release more options > Sync
- d5 Exposure delay mode > OFF
- d6\* Electronic front-curtain shutter > ON
- d7 File number sequence > ON
- d8\* Peaking highlight color > Y
- d9 \* Viewfinder grid display > ON
- d10 LCD illumination > OFF
- d11 Live view in continuous mode > ON

e Bracketing/flash

- e1\*Flash sync speed > 1/250\*
- e2\*Flash shutter speed > 1/2
- e3\* Exposure comp. for flash > Background only
- e4 Auto ⚡ ISO sensitivity control
- e5 Modeling flash > ON
- e6 Auto bracketing (mode M) > Flash/speed
- e7\*Bracketing order > Under>MTR>over

f Controls

- f1\* Custom control assignment > Pv > Viewfinder virtual horizon
  - > Fn1 > ⚡ Disable/enable flash
  - > Fn2 > Access top item MY MENU
  - > AF-ON > AF-ON
  - > Sub-selector > Focus point selection
  - > Sub-selector center > AE/AF lock
  - > BKT button + sub-command > Multiple exposure
  - > Movie record button > Choose image area
  - > Lens focus function buttons > AF lock only
- f2 Multi selector center button > Shooting mode > RESET
  - > Playback mode > Zoom on/off > Low magnification (50%)
  - > Live view > RESET
- f3 Shutter spd & aperture lock - -
- f4\* Customize command dials > Reverse rotation > Exposure compensation
  - > Change main/sub > Exposure setting > OFF
    - > Autofocusing setting > OFF
  - > Aperture setting > ON > Sub-command dial
  - > Menus and playback > ON
  - > Sub-dial frame advance > 10
- f5 Multi selector > OFF
- f6 Release button to use dial > OFF
- f7 Reverse indicators > - 0 +
- f8 Live view button options > ON
- f9 \* switch > \*
- f10 Assign MB-D18 buttons - -

## g Movie

- g1\* Custom control assignment > Pv > Power aperture (open)
  - > Shutter Release > Record movies
- g2\* Highlight brightness > 235

## SETUP MENU

- Format memory card - -
- Language > Polski
- Time zone and date – (always set to current location)
- Monitor brightness – 0
- Monitor color balance - -
- Virtual horizon - -
- Information display > W > Light on dark
- AF fine-tune - -
- Non-CPU lens data – No.1
- Lock mirror up for cleaning - -
- Image Dust Off ref photo - -
- Image comment – OFF
- Copyright information – ON
- Beep options - -
- Touch controls > ON

HDMI > Output resolution > Auto  
> External recording control > OFF  
> Advanced  
> Output range > Auto  
> Output display size > 100%  
> Live view on-screen display > ON  
> Dual monitor > ON

Location data –

Wireless remote (WR) options - -

Assign remote (WR) Fn button > AF-ON

Airplane mode > OFF

Connect to smart device - -

Send to smart device (auto) > OFF

Wi-Fi - -

Bluetooth > OFF (grayed out)

Network (grayed out)

Conformity marking - -

MB-D18 battery type

Battery order > MB-D18

Battery info

Slot empty release lock > OK

Save/load settings - -

Reset all settings - -

Firmware version - -

## **MY MENU**

Group flash options

Time zone and date

Lock mirror up for cleaning

Clean image sensor

Focus shift shooting

Time-lapse movie

Multiple exposure mode

Connect to smart device

**i > Movie > Lv**

FX

2160p30

HIGH

OFF

10

ATT-OFF

Wide

ON

SD

0

PV-ON  
+/- OFF  
Zebra ON  
15  
VR-OFF  
PEAK-OFF

blank = default

\* = modified