

Nikon Z 30 Settings

08.04.22 Settings

Firmware 1.00

PLAYBACK MENU

Delete

Playback folder – ALL

Playback display options > Additional photo info

> Exposure info

> Highlights

> Shooting data

> None (picture only)

Picture review - OFF

Rotate tall > OFF

Slide show

Rating

PHOTO SHOOTING MENU

Reset photo shooting menu

Storage folder – NZ30

File naming – BMP

Choose image area > DX

Image quality - RAW

Image size - L

RAW recording > 14-bit

ISO sensitivity settings > 100

> Auto ISO sensitivity control – OFF

White balance > Auto1

Set Picture Control > A Auto

> Standard > Sharpening +5 > Mid-range sharpening +5 > Clarity +1

> Monochrome > Sharpening +5 > Mid-range sharpening +5 > Clarity +4 > Contrast +2 > Filter effects R

> Flat > Sharpening +5 > Mid-range sharpening +5 > Clarity +1

Manage Picture Control

Color Space > Adobe

Active D-Lighting – OFF

Long exposure NR – OFF

High ISO NR – OFF

Vignette control – N

Diffraction compensation - ON

Auto distortion control – ON

Flicker reduction shooting - OFF

Metering - Matrix

Flash control (grayed out unless WR-R10/11a connected) WR-R11a connected

> CMD

> Flash compensation –

> Flash compensation (TTL) 0.0

- > Wireless flash options > Radio AWL
- > Remote flash control > GRP
- > Group flash options > Group A > M > 1/16
- > Radio remote flash info

Flash mode

Flash compensation

Release mode > Continuous H (extended)

Focus mode -- AF-C

AF-area mode > Wide-area AF (L-people)

Vibration reduction > ON > Normal

Auto bracketing set > AE⚡

Multiple exposure – OFF

HDR overlay - OFF

Interval timer shooting – OFF

Time-lapse video - OFF

Focus shift shooting – OFF

Silent photography - OFF

VIDEO RECORDING MENU

Reset video recording menu

File naming > BMP

Frame size/frame rate – 2160/30

Video quality > HIGH

Video file type > MOV

ISO sensitivity settings > Maximum sensitivity > 10000

> Auto ISO control (mode M) > OFF

> ISO sensitivity (mode M) > 100

White balance > Natural light auto

Set Picture Control > FL

Manage Picture Control > - -

Active D-Lighting > OFF

HIGH ISO NR > OFF

Vignette control - N

Diffraction compensation - ON

Auto distortion control - ON

Flicker reduction > Auto

Metering – Matrix

Release mode (save frame) -- Continuous

Focus Mode – AF-F

AF-area mode – Auto-area AF (people)

Vibration reduction > ON > Normal

Electronic VR - OFF

Microphone sensitivity > Manual sensitivity > 15

Attenuator > ON

Frequency response > Voice

Wind noise reduction > ON

Timecode –

CUSTOM SETTING MENU

Reset custom settings

a Autofocus

- a1* AF-C priority selection > Focus
- a2 AF-S priority selection > Focus
- a3* Focus tracking with lock-on > Blocked shot AF response > 4
- a4 Focus points used > ALL
- a5* Store by orientation > ON
- a6* AF activation > OFF > AF-ON only
- a7* Limit AF-area mode selection > Pinpoint
 - > Wide-area AF (L-people)
 - > Wide-area AF (L-animals)
 - > Auto-area AF
 - > Auto-area AF (people)
 - > Auto-area AF (animals)
- a8* Focus point wrap-around > ON
- a9 Focus point options
- a10 Low-light AF - ON

b Metering/exposure

- b1 Easy exposure compensation – OFF
- b2 Center-weighted area – (*) 8
- b3 Fine-tune optimal exposure - -

c Timers/AE lock

- c1 Shutter-release button AE-L > OFF
- c2* Self-timer > Self-timer delay > 2s
 - > Number of shots > 9
 - > Interval between shots > 0.5s
- c3* Power off delay > Playback 20s
 - > Menus 1m
 - >Image review 10s
 - >Standby times 30s

d Shooting/display

- d1 CL mode shooting speed > 4
- d2 Maximum shots per burst > 100
- d3 Exposure delay mode – OFF
- d4 Shutter type - Auto
- d5 File number sequence > ON
- d6* Apply settings to live view - OFF
- d7 Framing grid display – OFF
- d8* Focusing peaking > Peaking level >
 - > Peaking highlight color
- d9 View all in continuous mode – ON

e Bracketing/flash

- e1 Flash sync speed > 1/200
- e2 Flash shutter speed > 1/60
- e3* Exposure comp. for flash > Background only

e4* Auto ⚡ ISO sensitivity control > Subject only

e5 Auto bracketing (mode M) > Flash/speed

e6* Bracketing order > Under>MTR>over

f Controls

f1* Customize *i* menu > Set Picture Control > White balance > Choose image area > Wi-Fi connection
> Release mode > AF-area mode > Flash mode > Flash compensation
Multiple exposure > Active D-lighting > Vibration reduction > Focus mode

f2* Custom controls (shooting) > Fn1 > Playback
> Fn2 > Framing grid
> AE-L/AF-L button > AF-ON
> OK > Zoom on/off
> Video record button > None
> Lens Fn ring (clockwise) > None
> Lens Fn2 ring (counterclockwise) > None
> Lens control ring > OFF

f3* Custom controls (playback) > all the defaults

f4 Customize command dials

f5 Release button to use dial

f6* Reverse indicators +0-

g Video

g1* Customize *i* menu > Frame size and rate/Video Quality > Set Picture Control > Microphone sensitivity >
Highlight display > Frequency response > AF-areas mode > White Balance > Focus
mode> Focus peaking > Bluetooth connection > Release mode > Vibration reduction

g2* Custom control assignment > Fn1 > Playback
> Fn2 > Framing grid display
> AF-ON button > Fast AF-ON
> OK button > Zoom on/off
> Shutter-release button > Record videos
> Lens Fn button > OFF
> Lens Fn button > OFF
> Lens control ring > OFF

g3 AF speed - 5

g4 AF tracking sensitivity – 4

g5 Highlight display > ON > 248

SETUP MENU

Format memory card - -

Save user settings –

Reset user settings --

Language > English

Time zone and date – (always set to current location)

Monitor brightness – 0

Monitor color balance –

REC lamp brightness > Video recording > 3

> Time-lapse video recording > 3

Information display - B

AF fine-tuning options - OFF

Non-CPU lens data – No.1
Save focus position – OFF
Image Dust Off ref photo
Pixel mapping
Image comment – OFF
Copyright information – ON
Beep options – OFF
Touch controls – ON
Self-portrait mode – ON
HDMI
Airplane mode – OFF
Connect to smart device – OFF
Connect to computer – OFF
Wireless remote (ML-17) options
Conformity marking
USB power delivery – ON
Energy saving (photo mode) – ON
Slot empty release lock – OK
Save/load menu settings –
Reset all settings –
Firmware version –

RETOUCH MENU

All the defaults

MY MENU

Time zone and date
Format memory card
Time-lapse video
Connect to smart device

blank = default

* = modified